

PRODUCT PART NUMBER CHANGE ANNOUNCEMENT : AFFECTED PART NUMBERS

04/16/2009 r03

sensors worldwide



**PRODUCT PART NUMBER CHANGE ANNOUNCEMENT : AFFECTED PART NUMBERS**  
**CAPACITIVE PRODUCT SERIES: BCS, SK, SK1, SV and SNG.**

<b>OLD Part Number</b> <i>valid until March, 31st, 2009</i>	<b>NEW Order Code</b> <i>valid from April 1st, 2009</i>	<b>NEW Part Number</b>
BCS M18KM3-PSC80G-BV02	<b>BCS000E</b>	BCS M18KM3-PSC80G-BV02
BCS M18KM3-PSC80G-S04G	<b>BCS000H</b>	BCS M18KM3-PSC80G-S04G
BCS M18KM3-POC80G-BV02	<b>BCS000A</b>	BCS M18KM3-POC80G-BV02
BCS M18KM3-POC80G-S04G-001	<b>BCS000C</b>	BCS M18KM3-POC80G-S04G-001
BCS M18KM3-NSC80G-BV02	<b>BCS0009</b>	BCS M18KM3-NSC80G-BV02
BCS M18KM3-NOC80G-BV02	<b>BCS0008</b>	BCS M18KM3-NOC80G-BV02
BCS M30KN2-PSC18G-AV02	<b>BCS000R</b>	BCS M30KN2-PSC18G-AV02
BCS M30KN2-POC15G-AV02	<b>BCS000P</b>	BCS M30KN2-POC15G-AV02
BCS M30KN2-NSC18G-AV02	<b>BCS000N</b>	BCS M30KN2-NSC18G-AV02
BCS M30KN2-NOC15G-AV02	<b>BCS000M</b>	BCS M30KN2-NOC15G-AV02
BCS M30KM7-PPH15G-S04U	<b>BCS000L</b>	BCS M30KM7-PPH15G-S04U
BCS G34KN2-PSC24G-AV02	<b>BCS0005</b>	BCS G34KN2-PSC24G-AV02
BCS G34KN2-POC20G-AV02	<b>BCS0004</b>	BCS G34KN2-POC20G-AV02
BCS G34KN2-NSC24G-AV02	<b>BCS0003</b>	BCS G34KN2-NSC24G-AV02
BCS G34KN2-NOC20G-AV02	<b>BCS0002</b>	BCS G34KN2-NOC20G-AV02
BCS M18KM3-UST80G-BV02	<b>BCS000K</b>	BCS M18KM3-UST80G-BV02
BCS M18KM3-UOT80G-BV02	<b>BCS000J</b>	BCS M18KM3-UOT80G-BV02
BCS M30KN2-UST15G-AV02	<b>BCS000W</b>	BCS M30KN2-UST15G-AV02
BCS M30KN2-UOT15G-AV02	<b>BCS000U</b>	BCS M30KN2-UOT15G-AV02
BCS G34KN2-UST20G-AV02	<b>BCS0007</b>	BCS G34KN2-UST20G-AV02
BCS G34KN2-UOT20G-AV02	<b>BCS0006</b>	BCS G34KN2-UOT20G-AV02
BCS M08EG1-PSC15C-S49G	<b>BCS002A</b>	BCS M08T4E2-PSM15C-S49G
BCS M08EG1-POC15C-S49G	<b>BCS002C</b>	BCS M08T4E2-POM15C-S49G
BCS M08EG1-NSC15C-S49G	<b>BCS002E</b>	BCS M08T4E2-NSM15C-S49G
BCS M08EG-PSC30G-S49G	<b>BCS002M</b>	BCS M08T4E2-PSM30G-S49G
BCS 010-PSB-1-L-PU-02	<b>BCS002T</b>	BCS G10T4H-PSM40C-EP02
BCS 010-POB-1-L-PU-02	<b>BCS002U</b>	BCS G10T4H-POM40C-EP02
BCS 010-NSB-1-L-PU-02	<b>BCS002W</b>	BCS G10T4H-NSM40C-EP02
BCS 012-PSB-1-L-S4	<b>BCS0037</b>	BCS M12T4D2-PSM40C-S04G
BCS 012-POB-1-L-S4	<b>BCS0038</b>	BCS M12T4D2-POM40C-S04G
BCS 012-NSB-1-L-S4	<b>BCS0039</b>	BCS M12T4D2-NSM40C-S04G
BCS F50-GA-1-Y-PU-02	<b>BCS003K</b>	BCS D50O002-YPC25C-EV02
BCS F50-GA-1-Y-S49	<b>BCS003L</b>	BCS D50O003-YPC25C-S49G
BCS 012-PS-1-Y-02	<b>BCS003M</b>	BCS M12VVG1-PSM40C-EP02
BCS 012-PO-1-Y-02	<b>BCS003N</b>	BCS M12VVG1-POM40C-EP02
BCS 012-NS-1-Y-02	<b>BCS003P</b>	BCS M12VVG1-NSM40C-EP02
BCS 012-NO-1-Y-02	<b>BCS003R</b>	BCS M12VVG1-NOM40C-EP02
BCS R08KE-PSC80C-EP00,2-GS49	<b>BCS0055</b>	BCS R08RR01-PSM80C-EP00,02-GS49
BCS R08KE-POC80C-EP00,2-GS49	<b>BCS0056</b>	BCS R08RR01-POM80C-EP00,02-GS49
BCS 012-PS-1-L-S4	<b>BCS0062</b>	BCS M12T4D2-PSM80G-S49G
BCS 012-PO-1-L-S4	<b>BCS0063</b>	BCS M12T4D2-POM80G-S49G
BCS 012-NS-1-L-S4	<b>BCS0064</b>	BCS M12T4D2-NSM80G-S49G
BCS M18PI-PSC15F-BT02	<b>BCS0073</b>	BCS M18TTI2-PSC15G-AT02
BCS M18PI-POC15F-BT02	<b>BCS0074</b>	BCS M18TTI2-POC15G-AT02
BCS M18PI-NSC15F-BT02	<b>BCS0075</b>	BCS M18TTI2-NSC15G-AT02
BCS M18PI-NOC15F-BT02	<b>BCS0076</b>	BCS M18TTI2-NOC15G-AT02
BCS M30PH1-PSC30F-BT02	<b>BCS0077</b>	BCS M30TTH2-PSC30G-AT02
BCS M30PH1-POC30F-BT02	<b>BCS0078</b>	BCS M30TTH2-POC30G-AT02
BCS M30PH1-NSC30F-BT02	<b>BCS0079</b>	BCS M30TTH2-NSC30G-AT02

PRODUCT PART NUMBER CHANGE ANNOUNCEMENT : AFFECTED PART NUMBERS

BCS M30PH1-NOC30F-BT02	<b>BCS007A</b>	BCS M30TTH2-NOC30G-AT02
BCS R08KE-PSCFAC-EP00,2-GS49	<b>BCS008M</b>	BCS R08RR01-PSMFAC-EP00,02-GS49
BCS R08KE-POCFAC-EP00,2-GS49	<b>BCS008N</b>	BCS R08RR01-POMFAC-EP00,02-GS49
SKF-10-90/16/4-B-PC/PU	<b>BCS000Y</b>	BCS F01CP01-XXS10C-EP02-GZ01-002
SK-1-4-B-VA/PTFE	<b>BCS0010</b>	BCS G04T4D-XXS10C-EP02-GZ01-002
SK-1-M5-B-VA/PTFE	<b>BCS0011</b>	BCS M05T4C-XXS10C-EP02-GZ01-002
SK-1.5-6.5-B-VA/PTFE	<b>BCS0012</b>	BCS G06T4B-XXS15C-EP02-GZ01-002
SK-3-6.5-NB-VA/PTFE	<b>BCS0013</b>	BCS G06T4B-XXS30G-EP02-GZ01-002
SK-1.5-M8-B-VA/PTFE	<b>BCS0014</b>	BCS M08T4C-XXS15C-EP02-GZ01-002
SK-3-M8-NB-VA/PTFE	<b>BCS0015</b>	BCS M08T4C1-XXS30G-EP02-GZ01-002
SK-4-10-B-VA/PTFE	<b>BCS0016</b>	BCS G10T4B-XXS40C-EP02-GZ01-002
SK-8-10-NB-VA/PTFE	<b>BCS0017</b>	BCS G10T4C-XXS80G-EP02-GZ01-002
SK-4-M12-B-VA/PTFE	<b>BCS0018</b>	BCS M12T4D-XXS40C-EP02-GZ01-002
SK-8-M12-NB-VA/PTFE	<b>BCS0019</b>	BCS M12T4D1-XXS80G-EP02-GZ01-002
SK-3-18/2.5-B-VA/PTFE	<b>BCS001A</b>	BCS D18T403-XXS30C-EP02-GZ01-002
SK-5-18/4-B-VA/PTFE	<b>BCS001C</b>	BCS D18T404-XXS50C-EP02-GZ01-002
SK-5-18/10-B-VA/PTFE	<b>BCS001E</b>	BCS D18T407-XXS50C-EP02-GZ01-002
SK-10-22/4-B-VA/PTFE	<b>BCS001F</b>	BCS D22T405-XXS10C-EP02-GZ01-002
SK-10-22/10-B-VA/PTFE	<b>BCS001H</b>	BCS D22T408-XXS10C-EP02-GZ01-002
SK-15-30/4-B-VA/PTFE	<b>BCS001J</b>	BCS D30T406-XXS15C-EP02-GZ01-002
SK-15-30/10-B-VA/PTFE	<b>BCS001K</b>	BCS D30T409-XXS15C-EP02-GZ01-002
SV-45/30/15-PS	<b>BAE009E</b>	BAE SA-CS-001-PS
SV-45/30/15-PO	<b>BAE009F</b>	BAE SA-CS-001-PO
SV-45/30/15-NS	<b>BAE009H</b>	BAE SA-CS-001-NS
SV-45/30/15-NO	<b>BAE009J</b>	BAE SA-CS-001-NO
SNG-230AC-K	<b>BAE009K</b>	BAE SA-CS-006-XR
SNG-115AC-K	<b>BAE009L</b>	BAE SA-CS-007-XR
SNG-230AC-K-T	<b>BAE009M</b>	BAE SA-CS-008-XR
SNG-115AC-K-T	<b>BAE009N</b>	BAE SA-CS-009-XR
SV-2VX-LDG12	<b>BAE009P</b>	BAE SA-CS-002-YP
SV-X2L-LDG12	<b>BAE009R</b>	BAE SA-CS-003-YP
SNG-230AC-K-MinMax	<b>BAE009T</b>	BAE SA-CS-004-XR
SNG-115AC-K-MinMax	<b>BAE009U</b>	BAE SA-CS-005-XR
SK1-1.5-6.5-PBS-VA/PTFE	<b>BCS001L</b>	BCS G06T4E1-PSM15C-EP02
SK1-1.5-6.5-PBO-VA/PTFE	<b>BCS001M</b>	BCS G06T4E1-POM15C-EP02
SK1-1.5-6.5-NBS-VA/PTFE	<b>BCS001N</b>	BCS G06T4E1-NSM15C-EP02
SK1-1.5-6.5-NBO-VA/PTFE	<b>BCS001P</b>	BCS G06T4E1-NOM15C-EP02
SK1-1.5-6.5-PBS-VA/PTFE-Y1	<b>BCS001R</b>	BCS G06T4D2-PSM15C-S49G
SK1-1.5-6.5-PBO-VA/PTFE-Y1	<b>BCS001T</b>	BCS G06T4D2-POM15C-S49G
SK1-1.5-6.5-NBS-VA/PTFE-Y1	<b>BCS001U</b>	BCS G06T4D2-NSM15C-S49G
SK1-1.5-6.5-NBO-VA/PTFE-Y1	<b>BCS001W</b>	BCS G06T4D2-NOM15C-S49G
SK1-3-6.5-PNBS-VA/PTFE	<b>BCS001Y</b>	BCS G06T4E1-PSM30G-EP02
SK1-3-6.5-PNBO-VA/PTFE	<b>BCS001Z</b>	BCS G06T4E1-POM30G-EP02
SK1-3-6.5-NNBS-VA/PTFE	<b>BCS0020</b>	BCS G06T4E1-NSM30G-EP02
SK1-3-6.5-NNBO-VA/PTFE	<b>BCS0021</b>	BCS G06T4E1-NOM30G-EP02
SK1-3-6.5-PNBS-VA/PTFE-Y1	<b>BCS0022</b>	BCS G06T4D2-PSM30G-S49G
SK1-3-6.5-PNBO-VA/PTFE-Y1	<b>BCS0023</b>	BCS G06T4D2-POM30G-S49G
SK1-3-6.5-NNBS-VA/PTFE-Y1	<b>BCS0024</b>	BCS G06T4D2-NSM30G-S49G
SK1-3-6.5-NNBO-VA/PTFE-Y1	<b>BCS0025</b>	BCS G06T4D2-NOM30G-S49G
SK1-1.5-M8-PBS-VA/PTFE	<b>BCS0026</b>	BCS M08T4E1-PSM15C-EP02
SK1-1.5-M8-PBO-VA/PTFE	<b>BCS0027</b>	BCS M08T4E1-POM15C-EP02
SK1-1.5-M8-NBS-VA/PTFE	<b>BCS0028</b>	BCS M08T4E1-NSM15C-EP02
SK1-1.5-M8-NBO-VA/PTFE	<b>BCS0029</b>	BCS M08T4E1-NOM15C-EP02
SK1-1.5-M8-PBS-VA/PTFE-Y1	<b>BCS002A</b>	BCS M08T4E2-PSM15C-S49G
SK1-1.5-M8-PBO-VA/PTFE-Y1	<b>BCS002C</b>	BCS M08T4E2-POM15C-S49G
SK1-1.5-M8-NBS-VA/PTFE-Y1	<b>BCS002E</b>	BCS M08T4E2-NSM15C-S49G
SK1-1.5-M8-NBO-VA/PTFE-Y1	<b>BCS002F</b>	BCS M08T4E2-NOM15C-S49G
SK1-3-M8-PNBS-VA/PTFE	<b>BCS002H</b>	BCS M08T4E1-PSM30G-EP02
SK1-3-M8-PNBO-VA/PTFE	<b>BCS002J</b>	BCS M08T4E1-POM30G-EP02

PRODUCT PART NUMBER CHANGE ANNOUNCEMENT : AFFECTED PART NUMBERS

SK1-3-M8-NNBS-VA/PTFE	<b>BCS002K</b>	BCS M08T4E1-NSM30G-EP02
SK1-3-M8-NNBO-VA/PTFE	<b>BCS002L</b>	BCS M08T4E1-NOM30G-EP02
SK1-3-M8-PNBS-VA/PTFE-Y1	<b>BCS002M</b>	BCS M08T4E2-PSM30G-S49G
SK1-3-M8-PNBO-VA/PTFE-Y1	<b>BCS002N</b>	BCS M08T4E2-POM30G-S49G
SK1-3-M8-NNBS-VA/PTFE-Y1	<b>BCS002P</b>	BCS M08T4E2-NSM30G-S49G
SK1-3-M8-NNBO-VA/PTFE-Y1	<b>BCS002R</b>	BCS M08T4E2-NOM30G-S49G
SK1-4-10-PBS-VA/PTFE	<b>BCS002T</b>	BCS G10T4H-PSM40C-EP02
SK1-4-10-PBO-VA/PTFE	<b>BCS002U</b>	BCS G10T4H-POM40C-EP02
SK1-4-10-NBS-VA/PTFE	<b>BCS002W</b>	BCS G10T4H-NSM40C-EP02
SK1-4-10-NBO-VA/PTFE	<b>BCS002Y</b>	BCS G10T4H-NOM40C-EP02
SK1-4-M12-PBS-VA/PTFE	<b>BCS002Z</b>	BCS M12T4G1-PSM40C-EP02
SK1-4-M12-PBO-VA/PTFE	<b>BCS0030</b>	BCS M12T4G1-POM40C-EP02
SK1-4-M12-NBS-VA/PTFE	<b>BCS0031</b>	BCS M12T4G1-NSM40C-EP02
SK1-4-M12-NBO-VA/PTFE	<b>BCS0032</b>	BCS M12T4G1-NOM40C-EP02
SK1-10-22-PBS-VA/PVC	<b>BCS0033</b>	BCS D22V4M1-PSC10C-EV02
SK1-10-22-PBO-VA/PVC	<b>BCS0034</b>	BCS D22V4M1-POC10C-EV02
SK1-10-22-NBS-VA/PVC	<b>BCS0035</b>	BCS D22V4M1-NSC10C-EV02
SK1-10-22-NBO-VA/PVC	<b>BCS0036</b>	BCS D22V4M1-NOC10C-EV02
SK1-4-M12-PBS-VA/PTFE-Y2	<b>BCS0037</b>	BCS M12T4D2-PSM40C-S04G
SK1-4-M12-PBO-VA/PTFE-Y2	<b>BCS0038</b>	BCS M12T4D2-POM40C-S04G
SK1-4-M12-NBS-VA/PTFE-Y2	<b>BCS0039</b>	BCS M12T4D2-NSM40C-S04G
SK1-4-M12-NBO-VA/PTFE-Y2	<b>BCS0039</b>	BCS M12T4D2-NOM40C-S04G
SK1-15-30/4-PBS-VA/PTFE	<b>BCS003A</b>	BCS D30T401-PSC15C-EP02
SK1-15-30/4-PBO-VA/PTFE	<b>BCS003C</b>	BCS D30T401-POC15C-EP02
SK1-15-30/4-NBS-VA/PTFE	<b>BCS003E</b>	BCS D30T401-NSC15C-EP02
SK1-15-30/4-NBO-VA/PTFE	<b>BCS003F</b>	BCS D30T401-NOC15C-EP02
SK1-6F-22/4-PBS-VA/PTFE	<b>BCS003H</b>	BCS D22T403-PSM60C-EP02
SK1-6F-22/4-NBS-VA/PTFE	<b>BCS003J</b>	BCS D22T403-NSM60C-EP02
SK1-25-50/10-XXB-POM	<b>BCS003K</b>	BCS D50O002-YPC25C-EV02
SK1-25-50/10-XXB-POM-Y1	<b>BCS003L</b>	BCS D50O003-YPC25C-S49G
SK1-4-M12-PBS-PVC	<b>BCS003M</b>	BCS M12VVG1-PSM40C-EP02
SK1-4-M12-PBO-PVC	<b>BCS003N</b>	BCS M12VVG1-POM40C-EP02
SK1-4-M12-NBS-PVC	<b>BCS003P</b>	BCS M12VVG1-NSM40C-EP02
SK1-4-M12-NBO-PVC	<b>BCS003R</b>	BCS M12VVG1-NOM40C-EP02
SK1-4-M12-PBS-PVC-Y2	<b>BCS003T</b>	BCS M12VVD2-PSM40C-S04G
SK1-4-M12-PBO-PVC-Y2	<b>BCS003U</b>	BCS M12VVD2-POM40C-S04G
SK1-4-M12-NBS-PVC-Y2	<b>BCS003W</b>	BCS M12VVD2-NSM40C-S04G
SK1-4-M12-NBO-PVC-Y2	<b>BCS003Y</b>	BCS M12VVD2-NOM40C-S04G
SK1-8-M18-PBS-PVC	<b>BCS003Z</b>	BCS M18VVM1-PSM80C-EV02
SK1-8-M18-PBS-VA/PBT	<b>BCS0040</b>	BCS M18B4M-PSC80C-EV02
SK1-8-M18-PBO-PVC	<b>BCS0041</b>	BCS M18VVM1-POM80C-EV02
SK1-8-M18-PBO-VA/PBT	<b>BCS0042</b>	BCS M18B4M-POC80C-EV02
SK1-8-M18-NBS-PVC	<b>BCS0043</b>	BCS M18VVM1-NSM80C-EV02
SK1-8-M18-NBS-VA/PBT	<b>BCS0044</b>	BCS M18B4M-NOC80C-EV02
SK1-8-M18-NBO-PVC	<b>BCS0045</b>	BCS M18VVM1-NOM80C-EV02
SK1-8-M18-NBO-VA/PBT	<b>BCS0044</b>	BCS M18B4M-NSC80C-EV02
SK1-8-M18-PBS-PVC-Y2	<b>BCS0046</b>	BCS M18VVG2-PSC80C-S04G
SK1-8-M18-PBS-VA/PBT-Y2	<b>BCS0047</b>	BCS M18B4G2-PSC80C-S04G
SK1-8-M18-PBO-PVC-Y2	<b>BCS0048</b>	BCS M18VVG2-POC80C-S04G
SK1-8-M18-PBO-VA/PBT-Y2	<b>BCS0049</b>	BCS M18B4G2-POC80C-S04G
SK1-8-M18-NBS-PVC-Y2	<b>BCS004A</b>	BCS M18VVG2-NSC80C-S04G
SK1-8-M18-NBS-VA/PBT-Y2	<b>BCS004C</b>	BCS M18B4G2-NSC80C-S04G
SK1-8-M18-NBO-PVC-Y2	<b>BCS004E</b>	BCS M18VVG2-NOC80C-S04G
SK1-8-M18-NBO-VA/PBT-Y2	<b>BCS004F</b>	BCS M18B4G2-NOC80C-S04G
SK1-20-30-PBX-VA/PBT	<b>BCS004H</b>	BCS D30B4M3-PPC20C-EP02
SK1-20-30-NBX-VA/PBT	<b>BCS004J</b>	BCS D30B4M3-NPC20C-EP02
SK1-20-M30-PBX-PBT	<b>BCS004K</b>	BCS M30BBM3-PPC20C-EP02
SK1-20-M30-NBX-PBT	<b>BCS004L</b>	BCS M30BBM3-NPC20C-EP02
SK1-20-M30-PBX-PBT-Y2	<b>BCS004M</b>	BCS M30BBM2-PPM20C-S04G

PRODUCT PART NUMBER CHANGE ANNOUNCEMENT : AFFECTED PART NUMBERS

SK1-20-M30-NBX-PBT-Y2	<b>BCS004N</b>	BCS M30BBM2-NPM20C-S04G
SK1-20-M30-PBX-VA/PBT	<b>BCS004P</b>	BCS M30B4M3-PPM20C-EP02
SK1-20-M30-NBX-VA/PBT	<b>BCS004R</b>	BCS M30B4M3-NPM20C-EP02
SK1-20-M30-PBX-VA/PBT-Y2	<b>BCS004T</b>	BCS M30B4M2-PPM20C-S04G
SK1-20-M30-NBX-VA/PBT-Y2	<b>BCS004U</b>	BCS M30B4M2-NPM20C-S04G
SK1-25-34-PBX-PVC	<b>BCS004W</b>	BCS G34VVM3-PPM20C-EP02
SK1-25-34-NBX-PVC	<b>BCS004Y</b>	BCS G34VVM3-NPM20C-EP02
SK1-25-34-PBX-PVC-Y2	<b>BCS004Z</b>	BCS G34VVM2-PPM20C-S04G
SK1-25-34-NBX-PVC-Y2	<b>BCS0050</b>	BCS G34VVM2-NPM20C-S04G
SK1-8-34/16/8-PBS-PP	<b>BCS0051</b>	BCS R08RR01-PSM80C-EP02
SK1-8-34/16/8-PBO-PP	<b>BCS0052</b>	BCS R08RR01-POM80C-EP02
SK1-8-34/16/8-NBS-PP	<b>BCS0053</b>	BCS R08RR01-NSM80C-EP02
SK1-8-34/16/8-NBO-PP	<b>BCS0054</b>	BCS R08RR01-NOM80C-EP02
SK1-8-34/16/8-PBS-PP-M2/Y1	<b>BCS0055</b>	BCS R08RR01-PSM80C-EP00,02-GS49
SK1-8-34/16/8-PBO-PP-M2/Y1	<b>BCS0056</b>	BCS R08RR01-POM80C-EP00,02-GS49
SK1-8-34/16/8-NBS-PP-M2/Y1	<b>BCS0057</b>	BCS R08RR01-NSM80C-EP00,02-GS49
SK1-8-34/16/8-NBO-PP-M2/Y1	<b>BCS0058</b>	BCS R08RR01-NOM80C-EP00,02-GS49
SK1-8-M12-PNBS-PVC	<b>BCS0059</b>	BCS M12VVG1-PSM80G-EP02
SK1-8-M12-PNBO-PVC	<b>BCS005A</b>	BCS M12VVG1-POM80G-EP02
SK1-8-M12-NNBS-PVC	<b>BCS005C</b>	BCS M12VVG1-NSM80G-EP02
SK1-8-M12-NNBO-PVC	<b>BCS005E</b>	BCS M12VVG1-NOM80G-EP02
SK1-8-M12-PNBS-VA/PTFE	<b>BCS005F</b>	BCS M12T4G1-PSM80G-EP02
SK1-8-M12-PNBO-VA/PTFE	<b>BCS005H</b>	BCS M12T4G1-POM80G-EP02
SK1-8-M12-NNBS-VA/PTFE	<b>BCS005J</b>	BCS M12T4G1-NSM80G-EP02
SK1-8-M12-NNBO-VA/PTFE	<b>BCS005K</b>	BCS M12T4G1-NOM80G-EP02
SK1-15-M18-PNBS-PVC	<b>BCS005L</b>	BCS M18VVI1-PSC15G-DV02
SK1-15-M18-PNBO-PVC	<b>BCS005M</b>	BCS M18VVI1-POC15G-DV02
SK1-15-M18-NNBS-PVC	<b>BCS005N</b>	BCS M18VVI1-NSC15G-DV02
SK1-15-M18-NNBO-PVC	<b>BCS005P</b>	BCS M18VVI1-NOC15G-DV02
SK1-15-M18-PNBS-VA/PTFE	<b>BCS005R</b>	BCS M18T4I1-PSC15G-DV02
SK1-15-M18-PNBO-VA/PTFE	<b>BCS005T</b>	BCS M18T4I1-POC15G-DV02
SK1-15-M18-NNBS-VA/PTFE	<b>BCS005U</b>	BCS M18T4I1-NSC15G-DV02
SK1-15-M18-NNBO-VA/PTFE	<b>BCS005W</b>	BCS M18T4I1-NOC15G-DV02
SK1-8-M12-PNBS-PVC-Y2	<b>BCS005Y</b>	BCS M12VVD2-PSM80G-S04G
SK1-8-M12-PNBO-PVC-Y2	<b>BCS005Z</b>	BCS M12VVD2-POM80G-S04G
SK1-8-M12-NNBS-PVC-Y2	<b>BCS0060</b>	BCS M12VVD2-NSM80G-S04G
SK1-8-M12-NNBO-PVC-Y2	<b>BCS0061</b>	BCS M12VVD2-NOM80G-S04G
SK1-8-M12-PNBS-VA/PTFE-Y2	<b>BCS0062</b>	BCS M12T4D2-PSM80G-S04G
SK1-8-M12-PNBO-VA/PTFE-Y2	<b>BCS0063</b>	BCS M12T4D2-POM80G-S04G
SK1-8-M12-NNBS-VA/PTFE-Y2	<b>BCS0064</b>	BCS M12T4D2-NSM80G-S04G
SK1-8-M12-NNBO-VA/PTFE-Y2	<b>BCS0065</b>	BCS M12T4D2-NOM80G-S04G
SK1-15-M18-PNBS-PVC-Y2	<b>BCS0066</b>	BCS M18VVG2-PSC15G-S04G
SK1-15-M18-PNBO-PVC-Y2	<b>BCS0067</b>	BCS M18VVG2-POC15G-S04G
SK1-15-M18-NNBS-PVC-Y2	<b>BCS0068</b>	BCS M18VVG2-NSC15G-S04G
SK1-15-M18-NNBO-PVC-Y2	<b>BCS0069</b>	BCS M18VVG2-NOC15G-S04G
SK1-15-M18-PNBS-VA/PTFE-Y2	<b>BCS006A</b>	BCS M18T4G2-PSC15G-S04G
SK1-15-M18-PNBO-VA/PTFE-Y2	<b>BCS006C</b>	BCS M18T4G2-POC15G-S04G
SK1-15-M18-NNBS-VA/PTFE-Y2	<b>BCS006E</b>	BCS M18T4G2-NSC15G-S04G
SK1-15-M18-NNBO-VA/PTFE-Y2	<b>BCS006F</b>	BCS M18T4G2-NOC15G-S04G
SK1-HT125-FS-JM18-PS-VA/PTFE	<b>BCS006H</b>	BCS S01T401-PSCFNG-KM16-T02
SK1-HT125-FS-JM18-PO-VA/PTFE	<b>BCS006J</b>	BCS S01T401-POCFNG-KM16-T02
SK1-HT125-FS-JM18-NS-VA/PTFE	<b>BCS006K</b>	BCS S01T401-NSCFNG-KM16-T02
SK1-HT125-FS-JM18-NO-VA/PTFE	<b>BCS006L</b>	BCS S01T401-NOCFNG-KM16-T02
SK1-HT125-FS-JR3/8-PS-VA/PTFE	<b>BCS006M</b>	BCS S02T401-PSCFNG-KM16-T02
SK1-HT125-FS-JR3/8-PO-VA/PTFE	<b>BCS006N</b>	BCS S02T401-POCFNG-KM16-T02
SK1-HT125-FS-JR3/8-NS-VA/PTFE	<b>BCS006P</b>	BCS S02T401-NSCFNG-KM16-T02
SK1-HT125-FS-JR3/8-NO-VA/PTFE	<b>BCS006R</b>	BCS S02T401-NOCFNG-KM16-T02
SK1-HT125-FS-J3/8NPTF-PS-VA/PTFE	<b>BCS00A6</b>	BCS S03T401-PSCFNH-KM16-T02
SK1-HT125-FS-J3/8NPTF-PO-VA/PTFE	<b>BCS00A7</b>	BCS S03T401-POCFNH-KM16-T02

PRODUCT PART NUMBER CHANGE ANNOUNCEMENT : AFFECTED PART NUMBERS

SK1-HT125-FS-J3/8NPTF-NS-VA/PTFE	<b>BCS00A8</b>	BCS S03T401-NSCFNH-KM16-T02
SK1-HT125-FS-J3/8NPTF-NO-VA/PTFE	<b>BCS00A9</b>	BCS S03T401-NOCFNH-KM16-T02
SK1-TM-6-M12/60-PNBS-PVC	<b>BCS006T</b>	BCS M12VV11-PSM60G-EP02-E
SK1-TM-6-M12/60-PNBO-PVC	<b>BCS006U</b>	BCS M12VV11-POM60G-EP02-E
SK1-TM-6-M12/60-NNBS-PVC	<b>BCS006W</b>	BCS M12VV11-NSM60G-EP02-E
SK1-TM-6-M12/60-NNBO-PVC	<b>BCS006Y</b>	BCS M12VV11-NOM60G-EP02-E
SK1-TM-6-M12/63-PNBS-CPTFE	<b>BCS009J</b>	BCS M12TT11-PSM60G-ET02-E
SK1-TM-6-M12/63-PNBO-CPTFE	<b>BCS009K</b>	BCS M12TT11-POM60G-ET02-E
SK1-TM-6-M12/63-NNBS-CPTFE	<b>BCS009L</b>	BCS M12TT11-NSM60G-ET02-E
SK1-TM-6-M12/63-NNBO-CPTFE	<b>BCS009M</b>	BCS M12TT11-NOM60G-ET02-E
SK1-8-M12-PNBS-CPTFE	<b>BCS006Z</b>	BCS M12TTG1-PSM80G-ET02
SK1-8-M12-PNBO-CPTFE	<b>BCS0070</b>	BCS M12TTG1-POM80G-ET02
SK1-8-M12-NNBS-CPTFE	<b>BCS0071</b>	BCS M12TTG1-NSM80G-ET02
SK1-8-M12-NNBO-CPTFE	<b>BCS0072</b>	BCS M12TTG1-NOM80G-ET02
SK1-15-M18-PNBS-CPTFE	<b>BCS0073</b>	BCS M18TTI2-PSC15G-AT02
SK1-15-M18-PNBO-CPTFE	<b>BCS0074</b>	BCS M18TTI2-POC15G-AT02
SK1-15-M18-NNBS-CPTFE	<b>BCS0075</b>	BCS M18TTI2-NSC15G-AT02
SK1-15-M18-NNBO-CPTFE	<b>BCS0076</b>	BCS M18TTI2-NOC15G-AT02
SK1-30-M30-PNBS-CPTFE	<b>BCS0077</b>	BCS M30TTH2-PSC30G-AT02
SK1-30-M30-PNBO-CPTFE	<b>BCS0078</b>	BCS M30TTH2-POC30G-AT02
SK1-30-M30-NNBS-CPTFE	<b>BCS0079</b>	BCS M30TTH2-NSC30G-AT02
SK1-30-M30-NNBO-CPTFE	<b>BCS007A</b>	BCS M30TTH2-NOC30G-AT02
SK1-30-M30-PNBX-PBT	<b>BCS007C</b>	BCS M30BBM3-PPC30G-EP02
SK1-30-M30-NNBX-PBT	<b>BCS007E</b>	BCS M30BBM3-NPC30G-EP02
SK1-30-M30-PNBX-PBT-Y2	<b>BCS007F</b>	BCS M30BBM2-PPC30G-S04G
SK1-30-M30-NNBX-PBT-Y2	<b>BCS007H</b>	BCS M30BBM2-NPC30G-S04G
SK1-30-M30-PNBX-VA/PTFE	<b>BCS007J</b>	BCS M30T4M3-PPC30G-EP02
SK1-30-M30-NNBX-VA/PTFE	<b>BCS007K</b>	BCS M30T4M3-NPC30G-EP02
SK1-30-M30-PNBX-VA/PTFE-Y2	<b>BCS007L</b>	BCS M30T4M2-PPC30G-S04G
SK1-30-M30-NNBX-VA/PTFE-Y2	<b>BCS007M</b>	BCS M30T4M2-NPC30G-S04G
SK1-FS-MLM12-XDC-PSU	<b>BCS009N</b>	BCS S40SS01-GPCFNG-EP02
SK1-FS-MLG1/4-XDC-PSU	<b>BCS009P</b>	BCS S40SS02-GPCFNG-EP02
SK1-FS-MLNPT1/4-XDC-PSU	<b>BCS009R</b>	BCS S40SS03-GPCFNG-EP02
SK1-FS-MLM12-XDC-PSU-Y1	<b>BCS009T</b>	BCS S41SS01-GPCFNG-S49G
SK1-FS-MLG1/4-XDC-PSU-Y1	<b>BCS009U</b>	BCS S41SS02-GPCFNG-S49G
SK1-FS-MLNPT1/4-XDC-PSU-Y1	<b>BCS009W</b>	BCS S41SS03-GPCFNG-S49G
SK1-FS-MLRM12-XDC-PSU-Y1	<b>BCS009Y</b>	BCS S42SS01-GPCFNG-S49G
SK1-FS-MLRG1/4-XDC-PSU-Y1	<b>BCS009Z</b>	BCS S42SS02-GPCFNG-S49G
SK1-FS-MLRNPT1/4-XDC-PSU-Y1	<b>BCS00A0</b>	BCS S42SS03-GPCFNG-S49G
SK1-FSA-M18-PNBS-PVC	<b>BCS007N</b>	BCS M18VV11-PSCFAG-DV02
SK1-FSA-M18-PNBO-PVC	<b>BCS007P</b>	BCS M18VV11-POCFAG-DV02
SK1-FSA-M18-NNBS-PVC	<b>BCS007R</b>	BCS M18VV11-NSCFAG-DV02
SK1-FSA-M18-NNBO-PVC	<b>BCS007T</b>	BCS M18VV11-NOCFAG-DV02
SK1-FSA-M30-PNBX-PBT	<b>BCS007U</b>	BCS M30BBM3-PPCFAG-EP02
SK1-FSA-M30-NNBX-PBT	<b>BCS007W</b>	BCS M30BBM3-NPCFAG-EP02
SK1-FSA-M30-PNBX-PBT-Y2	<b>BCS007Y</b>	BCS M30BBM2-PPCFAG-S04G
SK1-FSA-M30-NNBX-PBT-Y2	<b>BCS007Z</b>	BCS M30BBM2-NPCFAG-S04G
SK1-FSA-50/10-PBS-CPTFE	<b>BCS0080</b>	BCS D50TT05-PSCFAC-ET02
SK1-FSA-50/10-PBO-CPTFE	<b>BCS0081</b>	BCS D50TT05-POCFAC-ET02
SK1-FSA-50/10-NBS-CPTFE	<b>BCS0082</b>	BCS D50TT05-NSCFAC-ET02
SK1-FSA-50/10-NBO-CPTFE	<b>BCS0083</b>	BCS D50TT05-NOCFAC-ET02
SK1-FSA-50/10-PBX-POM	<b>BCS0084</b>	BCS D50OO04-PPCFAC-EV02
SK1-FSA-50/10-NBX-POM	<b>BCS0085</b>	BCS D50OO04-NPCFAC-EV02
SK1-FSA-M30-PNBS-CPTFE	<b>BCS0086</b>	BCS M30TTH2-PSCFAG-AT02
SK1-FSA-M30-PNBO-CPTFE	<b>BCS0087</b>	BCS M30TTH2-POCFAG-AT02
SK1-FSA-M30-NNBS-CPTFE	<b>BCS0088</b>	BCS M30TTH2-NSCFAG-AT02
SK1-FSA-M30-NNBO-CPTFE	<b>BCS0089</b>	BCS M30TTH2-NOCFAG-AT02
SK1-FSA-M18-PNBS-CPTFE	<b>BCS008A</b>	BCS M18TTI2-PSCFAG-AT02
SK1-FSA-M18-PNBO-CPTFE	<b>BCS008C</b>	BCS M18TTI2-POCFAG-AT02

PRODUCT PART NUMBER CHANGE ANNOUNCEMENT : AFFECTED PART NUMBERS

SK1-FSA-M18-NNBS-CPTFE	<b>BCS008E</b>	BCS M18TTI2-NSCFAG-AT02
SK1-FSA-M18-NNBO-CPTFE	<b>BCS008F</b>	BCS M18TTI2-NOCFAG-AT02
SK1-FSA-34/16/8-PBS-PP	<b>BCS008H</b>	BCS R08RR01-PSMFAC-EP02
SK1-FSA-34/16/8-PBO-PP	<b>BCS008J</b>	BCS R08RR01-POMFAC-EP02
SK1-FSA-34/16/8-NBS-PP	<b>BCS008K</b>	BCS R08RR01-NSMFAC-EP02
SK1-FSA-34/16/8-NBO-PP	<b>BCS008L</b>	BCS R08RR01-NOMFAC-EP02
SK1-FSA-34/16/8-PBS-PP-M2/Y1	<b>BCS008M</b>	BCS R08RR01-PSMFAC-EP00,02-GS49
SK1-FSA-34/16/8-PBO-PP-M2/Y1	<b>BCS008N</b>	BCS R08RR01-POMFAC-EP00,02-GS49
SK1-FSA-34/16/8-NBS-PP-M2/Y1	<b>BCS008P</b>	BCS R08RR01-NSMFAC-EP00,02-GS49
SK1-FSA-34/16/8-NBO-PP-M2/Y1	<b>BCS008R</b>	BCS R08RR01-NOMFAC-EP00,02-GS49
SK1-FSA-M18-PNBS-PVC-Y1	<b>BCS008T</b>	BCS M18VVN-PSCFAG-S49G
SK1-FSA-M18-PNBO-PVC-Y1	<b>BCS008U</b>	BCS M18VVN-POCFAG-S49G
SK1-FSA-M18-NNBS-PVC-Y1	<b>BCS008W</b>	BCS M18VVN-NSCFAG-S49G
SK1-FSA-M18-NNBO-PVC-Y1	<b>BCS008Y</b>	BCS M18VVN-NOCFAG-S49G
SK1-FSA-MLM12-XDC-PSU	<b>BCS008Z</b>	BCS S40SS01-GPCFAG-EP02
SK1-FSA-MLG1/4-XDC-PSU	<b>BCS0090</b>	BCS S40SS02-GPCFAG-EP02
SK1-FSA-MLNPT1/4-XDC-PSU	<b>BCS0091</b>	BCS S40SS03-GPCFAG-EP02
SK1-FSA-MLM12-XDCS-PSU	<b>BCS0092</b>	BCS S40SS01-GPCFAG-EP02-D01
SK1-FSA-MLG1/4-XDCS-PSU	<b>BCS0093</b>	BCS S40SS02-GPCFAG-EP02-D01
SK1-FSA-MLNPT1/4-XDCS-PSU	<b>BCS0094</b>	BCS S40SS03-GPCFAG-EP02-D01
SK1-FSA-MLM12-XDC-PSU-Y1	<b>BCS0095</b>	BCS S41SS01-GPCFAG-S49G
SK1-FSA-MLG1/4-XDC-PSU-Y1	<b>BCS0096</b>	BCS S41SS02-GPCFAG-S49G
SK1-FSA-MLNPT1/4-XDC-PSU-Y1	<b>BCS0097</b>	BCS S41SS03-GPCFAG-S49G
SK1-FSA-MLRM12-XDC-PSU-Y1	<b>BCS0098</b>	BCS S42SS01-GPCFAG-S49G
SK1-FSA-MLRG1/4-XDC-PSU-Y1	<b>BCS0099</b>	BCS S42SS02-GPCFAG-S49G
SK1-FSA-MLRNPT1/4-XDC-PSU-Y1	<b>BCS009A</b>	BCS S42SS03-GPCFAG-S49G
SK1-FSA-D7B9/52-PNBS-CPTFE	<b>BCS009C</b>	BCS S20TT01-PSLFAG-ET02
SK1-FSA-D7B9/52-PNBO-CPTFE	<b>BCS009E</b>	BCS S20TT01-POLFAG-ET02
SK1-FSA-D7B9/52-NNBS-CPTFE	<b>BCS009F</b>	BCS S20TT01-NSLFAG-ET02
SK1-FSA-D7B9/52-NNBO-CPTFE	<b>BCS009H</b>	BCS S20TT01-NOLFAG-ET02
SK1-A-8-M18-4I20B-VA/PBT	<b>BCW0001</b>	BCW M18B4M1-ICM80C-DV02
SK-HT250-10-M18-NB-VA/PTFE	<b>BCS00A1</b>	BCS M18T4H1-XXS10H-SZ02-T08
SK-HT250-20-M30-NB-VA/PTFE	<b>BCS00A2</b>	BCS M30T4G1-XXS20H-SZ02-T08
SK-HT180-FS-M18-VA/PTFE	<b>BCS00A3</b>	BCS S10T401-XXSFNC-SZ02-T07
SK-HT180-FS-R3/8-VA/PTFE	<b>BCS00A4</b>	BCS S10T402-XXSFNC-SZ02-T07
SK-HT180-FS-J3/8NPTF-VA/PTFE	<b>BCS00A5</b>	BCS S10T403-XXSFNC-SZ02-T07
SLK-HT	<b>BCC04JW</b>	BCC Z003-020
SNG-230AC/24DC-T	<b>BAE009W</b>	BAE SA-XE-010-XR
SNG-115AC/24DC-T	<b>BAE009Y</b>	BAE SA-XE-011-XR
SNG-230AC-MINMAX	<b>BAE009T</b>	BAE SA-XE-012-XR
SNG-115AC-MINMAX	<b>BAE009U</b>	BAE SA-XE-013-XR
MA-M18/M30/10-VA	<b>BAM018E</b>	BAM AD-XA-001-M18/M30-4
MA-M18/M32/10-VA	<b>BAM018F</b>	BAM AD-XA-001-M18/M32x1,5-4
MA-M18/R1/10-VA	<b>BAM018H</b>	BAM AD-XA-001-M18/R1"-4
MSA-MLM12/M18X1-VA	<b>BAM018J</b>	BAM AD-XA-002-M12/M18-4
MSA-MLM12/G1/2-VA	<b>BAM018K</b>	BAM AD-XA-002-M12/G1/2"-4
Y2-M16	<b>BCC04JT</b>	BCC M454-0000-2A-RM004-020
SL-YA-M20	<b>BCC04JU</b>	BCC Z001-002
SL-YAZA-3m	<b>BCC04JY</b>	BCC Z002-030
SL-YAZA-8m	<b>BCC04JZ</b>	BCC Z002-080

**Contact us**

For more information contact our Customer Service at 1-800-543-8390 or your local sales representative representative.